

Kości zawieszenia

Instrukcja instalacji

1. Postaw motocykl na stopce centralnej, lub podwieś tył motocykla. Nie używaj do podparcia stopki bocznej - motocykl się przewróci! Wahacz za chwilę zostanie odłączony od reszty zawieszenia.
2. Fabryczne kości przykręcone są śrubami z łbem pod klucz 17mm, oraz nakrętkami pod klucz 17mm. Użyj nasadki 17mm oraz klucza 17mm, by odkręcić nakrętki i następnie wysunąć śruby. Obie śruby są identyczne, więc nie musisz przejmować się która gdzie się znajdowała.
4. Przymocuj nowe kości na miejscu fabrycznych przy pomocy śrub.
5. Nałóż nakrętki i dokręć je z momentem 50Nm.

Yamaha XT660Z Ténéré

Suspension links

Installation manual

1. Put the bike on the centerstand, or hang it from the ceiling. Do not use a sidestand or a track stand - the motorcycle will fall down! The swingarm will be disconnected from the rear shock soon.
2. The stock linkages are screwed with bolts with 17mm heads and 17mm nuts. Use a 17mm socket and a 17mm wrench to remove the nuts, and pull the screws out. They're identical, so you don't need to care of which one is where placed.
4. Set the new linkages in the place of the stock ones using the screws.
5. Put the nuts on a screws and tighten them with a torque of 50Nm (~36.9 lb-ft).

