



Michał Piekar Inżynieria
ul. Brzeziny 43
44-337 Jastrzębie-Zdrój
NIP: 6332219909 REGON: 360956627






tel. +48 506204080
e-mail: michal.piekar@advalp.pl
web: advalp.pl

00067

Poszerzenie stopki Yamaha XTZ750 Super Tenere

Instrukcja instalacji

Zestaw zawiera:



1. Przelóż przez otwory w płytce dolnej (1) trzy śruby (5).
2. Umieść stopkę centralną na płytce dolnej (1).
3. Nałóż na górę podstawy stopki płytkę górną (2).
4. Na śruby (5) wystające nad płytkę górną (2) nałóż podkładki (4), a następnie skręć połączenia nakrętkami (3) używając momentu 2,5 Nm.






Po przejechaniu pierwszych 50km sprawdź czy wszystkie połączenia gwintowe są dokręcone właściwym momentem.

M4 2,5 Nm 1.8 lb-ft

Yamaha XTZ750 Super Tenere side stand extension

Installation manual

Set includes:



1. Pass through the holes in the bottom plate (1) the three screws (5).
2. Place the side stand on the lower plate (1).
3. Apply to the top of the foot base, a top plate (2).
4. Apply the washers (4) to the screws (5) projecting on the top plate (2) and screw connection with the nuts (3) using a torque of 2.5 Nm (1.8 lb-ft).

Stopka boczna/
Side stand

After the first 50 km, check that all threaded connections are tightened to the correct torque.